

# 2Wire PC Port USB Driver Installation Instructions for Windows Computers

## **Introduction**

This document describes the procedure to install the Windows USB driver for the 2Wire PC Port Phonenumber 10Mbps USB Adapter. Notice that 2Wire has two different models of PC Port. This driver is for use with the model with one phone jack only.

## **Installation procedure for Windows 98/2000/ME/XP**

1. Turn on the power of your PC to boot from Windows 98/2000/ME/XP.
2. Plug 2Wire PC Port Phonenumber 10Mbps USB Adapter into one of the USB ports on your PC. Windows 98/2000/ME/XP may auto-detect your new adapter, and the "New Hardware Found" dialog box will appear.
3. Specify the path of the driver in your installation subdirectory (e.g. C:\TWUSB\_TEMP) to copy the driver file to your PC.
4. Press "NEXT" then select "Search for the best driver for your device."
5. When the driver installation is completed, restart Windows if your system has Windows 98 or Windows ME. You do not need to restart Windows for Windows 2000 or Windows XP.
6. After your computer restarts (only in the case of Windows 98 or Windows ME), configure the parameter settings in the "Network" configuration, if needed.

NOTE: Most users will not have to do this, especially if you have an IP address assigned to the PC Port automatically from the 2Wire gateway.